

AMPLIFIER

2005 Amplifier / Apartment Station Crossover Chart

HOUSING DEVICES ACS - 30	1	2	3		5		B	SP	SP	PO	DR	DR	AC	AC	
HOUSING DEVICES ACS - 35	1	2	3	4	5	6	B or BV	SP	SP1	PO	DO	AC2	AC1	AC2	NOTE 4
COUCH T350 (24v only)	1	7	6		10		9	3	4		11	12	AC1	AC2	NOTE 1 & 2
COUCH T356-E (24v only)	1& 6	7	5		10		9	3	4		13	12	13	14	NOTE 1 & 2
JERON / GREYSTONE	C	L			D		S	SP	SP		DR	DR	AC	AC	
MIRTONE 401	2	1	3				Z	S1	S2	P	L2	L1	T1	T2	
MIRTONE 210	B	A	C		D		E	S1	S2		L2	L1	T1	T2	
TEKTONE 101	1	2	3		4		Z	A	G	E	L2	DR	K	C	
TEKTONE 104	1	2	3				Z	A	G	E	L3	DR	K	C	
TEKTONE 543	1	2	3		5		ZW or Z	G	A	E	D**	K**	K	C	
AMER DEVICES (AD700)	A	C	B		D		LB	S	S		DR		AC	AC	
FLORENCE (FMC 10,20,30/30L)	C		2	3		1	P	SC	S	TD	B	AC1	AC	AC	NOTE 4
FLORENCE (FMC 35/35L)	C	3	2				P	SC	S	TD	B	DR	AC	AC	
AF 1000	C	PT4W	T	PT	T3W	D	B/BW*	SC	S	PDR	DO	AC2	AC1	AC2	NOTE 3
AUTH 3088	C & (-)	PT	T		D		Z	V1	V2		DO	AC2	AC1	AC2	NOTE 5
AUTH 2620-3	C				T		B	V1	V2	PDR	DO	AC2	AC1	AC2	
AUTH 2620-4	C	PT	T				B	V1	V2	PDR	DO	AC2	AC1	AC2	
AUTH 2620-6	C		T	PT		D	B/BW*	V1	V2	PDR	DO	AC2	AC1	AC2	NOTE 5

NOTE 1: Amplifier listed above require a 24V AC / 10VA - 30VA transformer.
NOTE 2: Crossover varies depending on whether a T350 or T356 amplifier is being used.
NOTE 3: If using a DC door strike use terminals L + and L - instead of DO and AC2 (ACS-35)
NOTE 4: Vestibule speaker return wire from C on FMC 10 connects to SP on ACS-35
NOTE 5: 6 wire system - (-) terminal to AC2
 * BV & BW = Warble Tone B = Steady Tone
 ** Used for DC Door = L(-) & L (+)




HOUSING DEVICES, INC
 407 REAR MYSTIC AVE. UNIT 32B
 MEDFORD, MA 02155
 781.395.5200
 781.395.8000 (FAX)
www.housingdevices.com

APARTMENT STATIONS HOOK-UPS TO AMPLIFIERS

HOUSING DEVICES ACS - 30 & ACS 35 AMPLIFIERS	1	2	3	5	BZ
ACS 4 COMMON	RED	YELLOW	BLUE	WHITE	BLACK
ACS 3 COMMON	BLACK	WHITE	RED	\	BLUE
ACS 2 COMMON	BLACK	\	\	RED	BLUE
MIRTONE 401 (3 COMMON)	WHITE (4)	BLACK (2)	RED (1)	\	GREEN (3)
TEKTONE 104 (3 COMMON)	BLACK (1)	WHITE (2)	RED (3)	\	BLUE (4)
TEKTONE 101	RED (C)	YELLOW (3)	BROWN (2)	WHITE (1)	BLACK (5)
COUCH T-350	2 & 4	5	1	6	3
COUCH T-356E	4	5	2	6	3
AMER DEVICES - AD 700	B	A	C	D	E
AUTH 3088	A	C	B	D	E
AUTH 2311	C & (-)	PT	T	D	Z
JERON / GREYSTONE	BLACK (C)	ORANGE (L)	\	BROWN (D)	GREEN (S)

NOTE: The above charts are *intended only as a guide* to aid in the substitution of Housing Device's amplifiers and apartment stations for those of other manufacturers. As all manufacturers continually make changes to their products, Housing Devices **cannot guarantee** that compatibility is assured.



Connections for 24 Volt Door Release